



Colonial rollformed, welded.

<i>Item Code</i>	<i>Description</i>
End Clip for Colonial Muntin 3/16" x 5/8" (welded)	
IGR 0508-0732	End Clip, Colonial Muntin 3/16"x5/8"; 7/32" air space
IGR 0508-0932	End Clip, Colonial Muntin 3/16"x5/8"; 9/32" air space
IGR 0508-1132	End Clip, Colonial Muntin 3/16"x5/8"; 11/32" air space
IGR 0508-1332	End Clip, Colonial Muntin 3/16"x5/8"; 13/32" air space
IGR 0508-1532	End Clip, Colonial Muntin 3/16"x5/8"; 15/32" air space
IGR 0508-1732	End Clip, Colonial Muntin 3/16"x5/8"; 17/32" air space
IGR 0508-1932	End Clip, Colonial Muntin 3/16"x5/8"; 19/32" air space
IGR 0508-2132	End Clip, Colonial Muntin 3/16"x5/8"; 21/32" air space
IGR 0508-2332	End Clip, Colonial Muntin 3/16"x5/8"; 23/32" air space
IGR 0508-2532	End Clip, Colonial Muntin 3/16"x5/8"; 25/32" air space

End Clip for Colonial Muntin 3/16" x 13/16" (welded)

IGR 1316-0732	End Clip, Colonial Muntin 3/16"x13/16"; 7/32" air space
IGR 1316-0932	End Clip, Colonial Muntin 3/16"x13/16"; 9/32" air space
IGR 1316-1132	End Clip, Colonial Muntin 3/16"x13/16"; 11/32" air space
IGR 1316-1332	End Clip, Colonial Muntin 3/16"x13/16"; 13/32" air space
IGR 1316-1532	End Clip, Colonial Muntin 3/16"x13/16"; 15/32" air space
IGR 1316-1732	End Clip, Colonial Muntin 3/16"x13/16"; 17/32" air space
IGR 1316-1932	End Clip, Colonial Muntin 3/16"x13/16"; 19/32" air space
IGR 1316-2132	End Clip, Colonial Muntin 3/16"x13/16"; 21/32" air space
IGR 1316-2332	End Clip, Colonial Muntin 3/16"x13/16"; 23/32" air space
IGR 1316-2532	End Clip, Colonial Muntin 3/16"x13/16"; 25/32" air space

Colonial rollformed, not welded.

End Clip for Colonial Muntin 3/16" x 5/8"

IHP 0508-0732	End Clip, Colonial Muntin 3/16"x5/8"; 7/32" air space
IHP 0508-0932	End Clip, Colonial Muntin 3/16"x5/8"; 9/32" air space
IHP 0508-1132	End Clip, Colonial Muntin 3/16"x5/8"; 11/32" air space
IHP 0508-1332	End Clip, Colonial Muntin 3/16"x5/8"; 13/32" air space
IHP 0508-1532	End Clip, Colonial Muntin 3/16"x5/8"; 15/32" air space
IHP 0508-1532-JW	End Clip, Colonial Muntin 3/16"x5/8"; 1/2" Spacer
IHP 0508-1732	End Clip, Colonial Muntin 3/16"x5/8"; 17/32" air space

Colonial rollformed, not welded.

IHP 0508-1932	End Clip, Colonial Muntin 3/16"x5/8"; 19/32" air space
IHP 0508-2132	End Clip, Colonial Muntin 3/16"x5/8"; 21/32" air space
IHP 0508-2332	End Clip, Colonial Muntin 3/16"x5/8"; 23/32" air space
IHP 0508-2532	End Clip, Colonial Muntin 3/16"x5/8"; 25/32" air space

End Clip for Colonial Muntin 3/16" x 5/8" / smaller design than 5/8 above

IHP 0508-0732-PH	End Clip, Colonial Muntin 3/16"x5/8"; 7/32" air space
IHP 0508-0932-PH	End Clip, Colonial Muntin 3/16"x5/8"; 9/32" air space
IHP 0508-1132-PH	End Clip, Colonial Muntin 3/16"x5/8"; 11/32" air space
IHP 0508-1332-PH	End Clip, Colonial Muntin 3/16"x5/8"; 13/32" air space
IHP 0508-1532-PH	End Clip, Colonial Muntin 3/16"x5/8"; 15/32" air space
IHP 0508-1532-PH-JW	End Clip, Colonial Muntin 3/16"x5/8"; 1/2" Spacer
IHP 0508-1732-PH	End Clip, Colonial Muntin 3/16"x5/8"; 17/32" air space
IHP 0508-1932-PH	End Clip, Colonial Muntin 3/16"x5/8"; 19/32" air space
IHP 0508-2132-PH	End Clip, Colonial Muntin 3/16"x5/8"; 21/32" air space
IHP 0508-2332-PH	End Clip, Colonial Muntin 3/16"x5/8"; 23/32" air space
IHP 0508-2532-PH	End Clip, Colonial Muntin 3/16"x5/8"; 25/32" air space

End Clip for Colonial Muntin 3/16" x 5/8" / for 0.024 material thickness

IHP 0508-0732-MI	End Clip, Colonial Muntin 3/16"x5/8"; 7/32" air space
IHP 0508-0932-MI	End Clip, Colonial Muntin 3/16"x5/8"; 9/32" air space
IHP 0508-1132-MI	End Clip, Colonial Muntin 3/16"x5/8"; 11/32" air space
IHP 0508-1332-MI	End Clip, Colonial Muntin 3/16"x5/8"; 13/32" air space
IHP 0508-1532-MI	End Clip, Colonial Muntin 3/16"x5/8"; 15/32" air space
IHP 0508-1532-MI-JW	End Clip, Colonial Muntin 3/16"x5/8"; 1/2" Spacer
IHP 0508-1732-MI	End Clip, Colonial Muntin 3/16"x5/8"; 17/32" air space
IHP 0508-1932-MI	End Clip, Colonial Muntin 3/16"x5/8"; 19/32" air space
IHP 0508-2132-MI	End Clip, Colonial Muntin 3/16"x5/8"; 21/32" air space
IHP 0508-2332-MI	End Clip, Colonial Muntin 3/16"x5/8"; 23/32" air space
IHP 0508-2532-MI	End Clip, Colonial Muntin 3/16"x5/8"; 25/32" air space

End Clip for Colonial Muntin 3/16" x 13/16"

IHP 1316-0732	End Clip, Colonial Muntin 3/16"x13/16"; 7/32" air space
IHP 1316-0932	End Clip, Colonial Muntin 3/16"x13/16"; 9/32" air space
IHP 1316-1132	End Clip, Colonial Muntin 3/16"x13/16"; 11/32" air space
IHP 1316-1332	End Clip, Colonial Muntin 3/16"x13/16"; 13/32" air space
IHP 1316-1532	End Clip, Colonial Muntin 3/16"x13/16"; 15/32" air space
IHP 1316-1732	End Clip, Colonial Muntin 3/16"x13/16"; 17/32" air space
IHP 1316-1932	End Clip, Colonial Muntin 3/16"x13/16"; 19/32" air space

Colonial rollformed, not welded.

IHP 1316-2132	End Clip, Colonial Muntin 3/16"x13/16";21/32" air space
IHP 1316-2332	End Clip, Colonial Muntin 3/16"x13/16";23/32" air space
IHP 1316-2532	End Clip, Colonial Muntin 3/16"x13/16";25/32" air space

End Clip for Colonial Muntin 3/16" x 3/4" (13/16 inside dimension)

IHP 0304-0732	End Clip, Colonial Muntin 3/16"x3/4"; 7/32" air space
IHP 0304-0932	End Clip, Colonial Muntin 3/16"x3/4"; 9/32" air space
IHP 0304-1132	End Clip, Colonial Muntin 3/16"x3/4"; 11/32" air space
IHP 0304-1332	End Clip, Colonial Muntin 3/16"x3/4"; 13/32" air space
IHP 0304-1532	End Clip, Colonial Muntin 3/16"x3/4"; 15/32" air space
IHP 0304-1732	End Clip, Colonial Muntin 3/16"x3/4"; 17/32" air space
IHP 0304-1932	End Clip, Colonial Muntin 3/16"x3/4"; 19/32" air space
IHP 0304-2132	End Clip, Colonial Muntin 3/16"x3/4"; 21/32" air space
IHP 0304-2332	End Clip, Colonial Muntin 3/16"x3/4"; 23/32" air space
IHP 0304-2532	End Clip, Colonial Muntin 3/16"x3/4"; 25/32" air space

End Clip for Colonial Muntin 1/4" x 5/8"

IHP 1458-0732	End Clip for 1/4"x5/8" Colonial Muntin; 7/32" air space
IHP 1458-0932	End Clip for 1/4"x5/8" Colonial Muntin; 9/32" air space
IHP 1458-1132	End Clip for 1/4"x5/8" Colonial Muntin; 11/32" air space
IHP 1458-1332	End Clip for 1/4"x5/8" Colonial Muntin; 13/32" air space
IHP 1458-1532	End Clip for 1/4"x5/8" Colonial Muntin; 15/32" air space
IHP 1458-1732	End Clip for 1/4"x5/8" Colonial Muntin; 17/32" air space
IHP 1458-1932	End Clip for 1/4"x5/8" Colonial Muntin; 19/32" air space
IHP 1458-2132	End Clip for 1/4"x5/8" Colonial Muntin; 21/32" air space
IHP 1458-2332	End Clip for 1/4"x5/8" Colonial Muntin; 23/32" air space
IHP 1458-2532	End Clip for 1/4"x5/8" Colonial Muntin; 25/32" air space

End Clip for Colonial Muntin 1/4" x 5/16"

IHP 14516-0932	End Clip for 1/4"x5/16" Pencil Muntin; 9/32" air space
IHP 14516-1132	End Clip for 1/4"x5/16" Pencil Muntin; 11/32" air space
IHP 14516-1332	End Clip for 1/4"x5/16" Pencil Muntin; 13/32" air space
IHP 14516-1532	End Clip for 1/4"x5/16" Pencil Muntin; 15/32" air space
IHP 14516-1732	End Clip for 1/4"x5/16" Pencil Muntin; 17/32" air space
IHP 14516-1932	End Clip for 1/4"x5/16" Pencil Muntin; 19/32" air space
IHP 14516-2132	End Clip for 1/4"x5/16" Pencil Muntin; 21/32" air space
IHP 14516-2332	End Clip for 1/4"x5/16" Pencil Muntin; 23/32" air space

End Clip for Colonial Muntin 3/16x9/16

IHP 0916-0932	End Clip for 3/16x9/16 Colonial Muntin; 9/32" air space
IHP 0916-1132	End Clip for 3/16x9/16 Colonial Muntin; 11/32" air space
IHP 0916-1332	End Clip for 3/16x9/16 Colonial Muntin; 13/32" air space
IHP 0916-1532	End Clip for 3/16x9/16 Colonial Muntin; 15/32" air space
IHP 0916-1732	End Clip for 3/16x9/16 Colonial Muntin; 17/32" air space
IHP 0916-1932	End Clip for 3/16x9/16 Colonial Muntin; 19/32" air space
IHP 0916-2132	End Clip for 3/16x9/16 Colonial Muntin; 21/32" air space
IHP 0916-2332	End Clip for 3/16x9/16 Colonial Muntin; 23/32" air space

End Clip for Colonial Muntin 3/8 x 7/16

IHP 38716-0932	End Clip for 3/8x7/16 Colonial Muntin; 9/32" air space
IHP 38716-1132	End Clip for 3/8x7/16 Colonial Muntin; 11/32" air space
IHP 38716-1332	End Clip for 3/8x7/16 Colonial Muntin; 13/32" air space
IHP 38716-1532	End Clip for 3/8x7/16 Colonial Muntin; 15/32" air space
IHP 38716-1732	End Clip for 3/8x7/16 Colonial Muntin; 17/32" air space
IHP 38716-1932	End Clip for 3/8x7/16 Colonial Muntin; 19/32" air space
IHP 38716-2132	End Clip for 3/8x7/16 Colonial Muntin; 21/32" air space
IHP 38716-2332	End Clip for 3/8x7/16 Colonial Muntin; 23/32" air space

End Clip for Colonial Muntin 3/8 x 5/8

IHP 3858-0932	End Clip for 3/8x5/8 Colonial Muntin; 9/32" air space
IHP 3858-1132	End Clip for 3/8x5/8 Colonial Muntin; 11/32" air space
IHP 3858-1332	End Clip for 3/8x5/8 Colonial Muntin; 13/32" air space
IHP 3858-1532	End Clip for 3/8x5/8 Colonial Muntin; 15/32" air space
IHP 3858-1732	End Clip for 3/8x5/8 Colonial Muntin; 17/32" air space
IHP 3858-1932	End Clip for 3/8x5/8 Colonial Muntin; 19/32" air space
IHP 3858-2132	End Clip for 3/8x5/8 Colonial Muntin; 21/32" air space
IHP 3858-2332	End Clip for 3/8x5/8 Colonial Muntin; 23/32" air space

Pencil Muntin

End Clip for Pencil Muntin 5/16" round

IHP-B 0516-0932	End Clip for 5/16 Pencil Muntin; 9/32" air space
IHP-B 0516-1132	End Clip for 5/16 Pencil Muntin; 11/32" air space
IHP-B 0516-1332	End Clip for 5/16 Pencil Muntin; 13/32" air space
IHP-B 0516-1532	End Clip for 5/16 Pencil Muntin; 15/32" air space
IHP-B 0516-1732	End Clip for 5/16 Pencil Muntin; 17/32" air space
IHP-B 0516-1932	End Clip for 5/16 Pencil Muntin; 19/32" air space
IHP-B 0516-2132	End Clip for 5/16 Pencil Muntin; 21/32" air space
IHP-B 0516-2332	End Clip for 5/16 Pencil Muntin; 23/32" air space

End clip, Pencil Muntin, (Helima 8x1.5)

INT 0815-0932	End Clip for Helima 8x1.5 Pencil Muntin; 9/32" air space
INT 0815-1132	End Clip for Helima 8x1.5 Pencil Muntin; 11/32" air space
INT 0815-1332	End Clip for Helima 8x1.5 Pencil Muntin; 13/32" air space
INT 0815-1532	End Clip for Helima 8x1.5 Pencil Muntin; 15/32" air space
INT 0815-1732	End Clip for Helima 8x1.5 Pencil Muntin; 17/32" air space
INT 0815-1932	End Clip for Helima 8x1.5 Pencil Muntin; 19/32" air space
INT 0815-2132	End Clip for Helima 8x1.5 Pencil Muntin; 21/32" air space
INT 0815-2332	End Clip for Helima 8x1.5 Pencil Muntin; 23/32" air space

End Clip for Decra Light Grid

IHP-PIN 0932	End Clip with pin for Decra Lite; 9/32" air space
IHP-PIN 1132	End Clip with pin for Decra Lite; 11/32" air space
IHP-PIN 1332	End Clip with pin for Decra Lite; 13/32" air space
IHP-PIN 1532	End Clip with pin for Decra Lite; 15/32" air space
IHP-PIN 1732	End Clip with pin for Decra Lite; 17/32" air space
IHP-PIN 1932	End Clip with pin for Decra Lite; 19/32" air space
IHP-PIN 2132	End Clip with pin for Decra Lite; 21/32" air space
IHP-PIN 2332	End Clip with pin for Decra Lite; 23/32" air space

Venecian or Contour Muntin, not welded.

End Clip for Contour Muntin 8 x 18

MLT 1808-0932	End Clip, Contour Muntin 18x8; 9/32" air space
MLT 1808-1132	End Clip, Contour Muntin 18x8; 11/32" air space
MLT 1808-1332	End Clip, Contour Muntin 18x8; 13/32" air space
MLT 1808-1532	End Clip, Contour Muntin 18x8; 15/32" air space
MLT 1808-1732	End Clip, Contour Muntin 18x8; 17/32" air space
MLT 1808-1932	End Clip, Contour Muntin 18x8; 19/32" air space
MLT 1808-2132	End Clip, Contour Muntin 18x8; 21/32" air space
MLT 1808-2332	End Clip, Contour Muntin 18x8; 23/32" air space

End Clip for Contour Muntin 5.5 x 18

INT-C 1855-0932	End Clip, Contour Muntin 18 x 5.5; 9/32" air space
INT-C 1855-1132	End Clip, Contour Muntin 18 x 5.5; 11/32" air space
INT-C 1855-1332	End Clip, Contour Muntin 18 x 5.5; 13/32" air space
INT-C 1855-1532	End Clip, Contour Muntin 18 x 5.5; 15/32" air space
INT-C 1855-1732	End Clip, Contour Muntin 18 x 5.5; 17/32" air space
INT-C 1855-1932	End Clip, Contour Muntin 18 x 5.5; 19/32" air space
INT-C 1855-2132	End Clip, Contour Muntin 18 x 5.5; 21/32" air space
INT-C 1855-2332	End Clip, Contour Muntin 18 x 5.5; 23/32" air space
INT-C 1855-2532	End Clip, Contour Muntin 18 x 5.5; 25/32" air space

End Clip for Contour Muntin 5.5 x 18 / slim design

IHP-S 1855-0932	End Clip, Contour Muntin 18 x 5.5; 9/32" air space
IHP-S 1855-1132	End Clip, Contour Muntin 18 x 5.5; 11/32" air space
IHP-S 1855-1332	End Clip, Contour Muntin 18 x 5.5; 13/32" air space
IHP-S 1855-1532	End Clip, Contour Muntin 18 x 5.5; 15/32" air space
IHP-S 1855-1732	End Clip, Contour Muntin 18 x 5.5; 17/32" air space
IHP-S 1855-1932	End Clip, Contour Muntin 18 x 5.5; 19/32" air space
IHP-S 1855-2132	End Clip, Contour Muntin 18 x 5.5; 21/32" air space
IHP-S 1855-2332	End Clip, Contour Muntin 18 x 5.5; 23/32" air space
INT-C 1855-2532	End Clip, Contour Muntin 18 x 5.5; 25/32" air space

End Clip for Contour Muntin 5.5 x 25

INT-C 2555-0932	End Clip for Contour Muntin, 25x5.5; 9/32" air space
INT-C 2555-1132	End Clip for Contour Muntin, 25x5.5; 11/32" air space
INT-C 2555-1332	End Clip for Contour Muntin, 25x5.5; 13/32" air space
INT-C 2555-1532	End Clip for Contour Muntin, 25x5.5; 15/32" air space
INT-C 2555-1732	End Clip for Contour Muntin, 25x5.5; 17/32" air space
INT-C 2555-1932	End Clip for Contour Muntin, 25x5.5; 19/32" air space
INT-C 2555-2132	End Clip for Contour Muntin, 25x5.5; 21/32" air space
INT-C 2555-2332	End Clip for Contour Muntin, 25x5.5; 23/32" air space

End Clip for Contour Muntin 5.5 x 25 / slim design

IHP-S 2555-0932	End Clip, Contour Muntin 25 x 5.5; 9/32" air space
IHP-S 2555-1132	End Clip, Contour Muntin 25 x 5.5; 11/32" air space
IHP-S 2555-1332	End Clip, Contour Muntin 25 x 5.5; 13/32" air space
IHP-S 2555-1532	End Clip, Contour Muntin 25 x 5.5; 15/32" air space
IHP-S 2555-1732	End Clip, Contour Muntin 25 x 5.5; 17/32" air space
IHP-S 2555-1932	End Clip, Contour Muntin 25 x 5.5; 19/32" air space
IHP-S 2555-2132	End Clip, Contour Muntin 25 x 5.5; 21/32" air space
IHP-S 2555-2332	End Clip, Contour Muntin 25 x 5.5; 23/32" air space
IHP-S 2555-2532	End Clip, Contour Muntin 25 x 5.5; 25/32" air space

End Clip for Contour Muntin 5.5 x 25 / super slim design

IHP-SS 2555-0932	End Clip, Contour Muntin 25 x 5.5; 9/32" air space
IHP-SS 2555-1132	End Clip, Contour Muntin 25 x 5.5; 11/32" air space
IHP-SS 2555-1332	End Clip, Contour Muntin 25 x 5.5; 13/32" air space
IHP-SS 2555-1532	End Clip, Contour Muntin 25 x 5.5; 15/32" air space
IHP-SS 2555-1732	End Clip, Contour Muntin 25 x 5.5; 17/32" air space
IHP-SS 2555-1932	End Clip, Contour Muntin 25 x 5.5; 19/32" air space
IHP-SS 2555-2132	End Clip, Contour Muntin 25 x 5.5; 21/32" air space
IHP-SS 2555-2332	End Clip, Contour Muntin 25 x 5.5; 23/32" air space
IHP-SS 2555-2532	End Clip, Contour Muntin 25 x 5.5; 25/32" air space

End Clip - Welded 8 x 26

INT-WCM 2608-1132	End Clip, Contour Muntin 26x8; 11/32" air space
INT-WCM 2608-1332	End Clip, Contour Muntin 26x8; 13/32" air space
INT-WCM 2608-1532	End Clip, Contour Muntin 26x8; 15/32" air space
INT-WCM 2608-1732	End Clip, Contour Muntin 26x8; 17/32" air space
INT-WCM 2608-1932	End Clip, Contour Muntin 26x8; 19/32" air space
INT-WCM 2608-2132	End Clip, Contour Muntin 26x8; 21/32" air space
INT-WCM 2608-2332	End Clip, Contour Muntin 26x8; 23/32" air space

End Clip for Helima Helvetion Muntin

End Clip - Extruded 18 x 8 (thick wall)

INT-E 1808-1132	End Clip, Contour Muntin	18x8; 11/32" air space
INT-E 1808-1332	End Clip, Contour Muntin	18x8; 13/32" air space
INT-E 1808-1532	End Clip, Contour Muntin	18x8; 15/32" air space
INT-E 1808-1732	End Clip, Contour Muntin	18x8; 17/32" air space
INT-E 1808-1932	End Clip, Contour Muntin	18x8; 19/32" air space
INT-E 1808-2132	End Clip, Contour Muntin	18x8; 21/32" air space
INT-E 1808-2332	End Clip, Contour Muntin	18x8; 23/32" air space

End Clip - Extruded 26 x 8 (thick wall)

INT-E 2608-1132	End Clip, Contour Muntin	18x8; 11/32" air space
INT-E 2608-1332	End Clip, Contour Muntin	18x8; 13/32" air space
INT-E 2608-1532	End Clip, Contour Muntin	18x8; 15/32" air space
INT-E 2608-1732	End Clip, Contour Muntin	18x8; 17/32" air space
INT-E 2608-1932	End Clip, Contour Muntin	18x8; 19/32" air space
INT-E 2608-2132	End Clip, Contour Muntin	18x8; 21/32" air space
INT-E 2608-2332	End Clip, Contour Muntin	18x8; 23/32" air space
INT-E 2608-2532	End Clip, Contour Muntin	18x8; 25/32" air space

End Clip - Welded 5 x 18

INT-W 1805-0732	End Clip, Contour Muntin	18x5; 7/32" air space
INT-W 1805-0932	End Clip, Contour Muntin	18x5; 9/32" air space
INT-W 1805-1132	End Clip, Contour Muntin	18x5; 11/32" air space
INT-W 1805-1332	End Clip, Contour Muntin	18x5; 13/32" air space
INT-W 1805-1532	End Clip, Contour Muntin	18x5; 15/32" air space
INT-W 1805-1732	End Clip, Contour Muntin	18x5; 17/32" air space
INT-W 1805-1932	End Clip, Contour Muntin	18x5; 19/32" air space
INT-W 1805-2132	End Clip, Contour Muntin	18x5; 21/32" air space
INT-W 1805-2332	End Clip, Contour Muntin	18x5; 23/32" air space

End Clip - Welded 8 x 18

INT-W 1808-1132	End Clip, Contour Muntin	18x8; 11/32" air space
INT-W 1808-1332	End Clip, Contour Muntin	18x8; 13/32" air space
INT-W 1808-1532	End Clip, Contour Muntin	18x8; 15/32" air space
INT-W 1808-1732	End Clip, Contour Muntin	18x8; 17/32" air space
INT-W 1808-1932	End Clip, Contour Muntin	18x8; 19/32" air space
INT-W 1808-2132	End Clip, Contour Muntin	18x8; 21/32" air space
INT-W 1808-2332	End Clip, Contour Muntin	18x8; 23/32" air space
INT-W 1808-2532	End Clip, Contour Muntin	18x8; 25/32" air space

End Clip - Welded 8 x 26

INT-W 2608-1132	End Clip, Contour Muntin 18x8; 11/32" air space
INT-W 2608-1332	End Clip, Contour Muntin 18x8; 13/32" air space
INT-W 2608-1532	End Clip, Contour Muntin 18x8; 15/32" air space
INT-W 2608-1732	End Clip, Contour Muntin 18x8; 17/32" air space
INT-W 2608-1932	End Clip, Contour Muntin 18x8; 19/32" air space
INT-W 2608-2132	End Clip, Contour Muntin 18x8; 21/32" air space
INT-W 2608-2332	End Clip, Contour Muntin 18x8; 23/32" air space
INT-W 2608-2532	End Clip, Contour Muntin 18x8; 25/32" air space

Muntin Joyner - standard

JO-CR 0508	Muntin joyner - Cross for 3/16 X 5/8 Muntin
JO-CR 1316	Muntin joyner - Cross for 3/16 X 13/16 Muntin

Muntin Joyner - interlocking

JO-SN 1316	Muntin joyner - locking for 3/16 x 13/16 Muntin
------------	-------------------------------------------------

Standard Terms

Shipping : FOB Durotech International, INC. Woodruff, SC 29388

Payment: 30 Day Net

Packing: Bulk pack

Ordering: Minimum order is 2,500 parts per article.
Order increments is 2,500 per article.